
GRILL GUARD FOR MITSUBISHI MONTERO SPORT 00-04

PARTS LIST

1-FRONT BAR	2-M10 U BOLTS	2-M8 HEX NUT
2-FRAME MOUNTING BRACKETS.	2-M10×100 HEX BOLTS	2-M8x25 HEX BOLTS
4-M12×35HEX BOLTS.	6-M10 HEX NUTS	2-Φ8 LOCK WASHERS
8-Φ12 FLAT WASHERS	8-Φ10 FLAT WASHERS	4-Φ8 FLAT WASHERS
4-Φ 12 LOCK WASHERS	6-Φ 10 LOCK WASHERS	
4-M12 HEX NUTS		

INSTALLING FRON BAR

1. REMOVE CONTENTS FROM BOX AND VERIFY ALL PART ARE PRESENT.READ INSTRUTIONS COMPLETELY BEFORE BEGINNING.
2. START WITH THE DRIVER SIDE ASSEMBLY, POSITION THE U BOLT UP THROUGH THE OBLONG HOLE IN THE SIDE OF THE HOOK (SEE THE FIGURE). ATTACH THE FRAME MOUNTING BRACKET TO THE SIDE OF THE HOOK, USING THE M10 NUT, M10×100 HEX BOTL,WASHERS.
3. RE-PEAT STEP1 TO INSTALL THE PASSENER SIDE.
4. ATTACH THE FRONT BAR ASSEMBLY TO THE BRACKETS USING THE M12×35 HEX BOLTS,M12 HEX NUTS AND Φ 12 FLAT WASHERS
5. ALIGN THE FRONT BAR ASSEMBLY WITH THE FRONT TO THE VEHICLE AND TIGHTEN ALL FASTENERS.

