



www.skyjacker.com

# 97-06 Jeep Wrangler TJ, 84-01 Cherokee XJ, & 93-98 Grand Cherokee ZJ Front Adjustable Track Bar Installation Instructions

## REQUIRED TOOL LIST:

- Safety Glasses
- Metric / Standard Wrenches & Sockets
- Measuring Tape
- Torque Wrench



Before beginning the installation, thoroughly & completely read these instructions & the enclosed driver's WARNING NOTICE. Affix the WARNING decal in the passenger compartment in clear view of all occupants. Please refer to the Parts List to insure that all parts & hardware are received prior to the disassembly of the vehicle. If any parts are found to be missing, contact SKYJACKER® Customer Service at 318-388-0816 to obtain the needed items. If you have any questions or reservations about the installation of this product, call SKYJACKER® Technical Assistance at 318-388-0816.

## Kit Box Breakdown:

### Part #: TBA10

ITEM#	DESCRIPTION	QTY
TBA10-B	TRACK BAR FOR JEEP	1
RE34X34R	ROD END 3/4" RIGHT HAND THR	1
34RFTJN	3/4" RIGHT HAND JAM NUT	1
7400WS	WHITE STEERING DAMPER	1
BTIE	RED BOOT TIE	1
B10RS	RED BOOT	1
NSS	NITRO SHOCK DECAL	1
I-TBA10	INSTRUCTIONS FOR TBA10	1
HB-TBA60	HDWR BAG FOR TBA10/60/80	1
WD1	WARNING DECAL	1

## Part #: TBA60

ITEM#	DESCRIPTION	QTY
TBA60-B	TRACK BAR FOR 6" TJ/XJ	1
RE34X34R	ROD END 3/4" RIGHT HAND THR	1
34RFTJN	3/4" RIGHT HAND JAM NUT	1
7400WS	WHITE STEERING DAMPER	1
BTIE	RED BOOT TIE	1
B10RS	RED BOOT	1
NSS	NITRO SHOCK DECAL	1
I-TBA10	INSTRUCTIONS FOR TBA10	1
HB-TBA60	HDWR BAG FOR TBA10/60/80	1
WD1	WARNING DECAL	1

## Part #: TBA80

ITEM#	DESCRIPTION	QTY
TBA80-B	FRONT TRACK BAR,8" TJ/XJ	1
RE34X34R	ROD END 3/4" RIGHT HAND THR	1
34RFTJN	3/4" RIGHT HAND JAM NUT	1
7400WS	WHITE STEERING DAMPER	1
BTIE	RED BOOT TIE	1
B10RS	RED BOOT	1
NSS	NITRO SHOCK DECAL	1
I-TBA10	INSTRUCTIONS FOR TBA10	1
HB-TBA60	HDWR BAG FOR TBA10/60/80	1
WD1	WARNING DECAL	1

### Hardware Bag Breakdown:

#### HB-TBA60                      HARDWARE BAG

ITEM#	DESCRIPTION	QTY
TJDLB	TJ DRAG LINK BUSHING,1.125"	2
12X212FSB	1/2 X 2 1/2 FLAT SOCKET BLT	1
12X312FTB	1/2 X 3 1/2 FINE THREAD BLT	1
12USSW	1/2 USS WASHER	1
12SAEW	1/2 SAE WASHER	1
12STVFTN	1/2" STOVER LKNUT, FINE THD	1
2888	BUSHING JEEP TRACK BAR	2
142121	ES24 SLEEVE/402087 1.38"	1
81004	TAPERED SLEEVE, 1/2" I.D.	1
LT100	NUTS N' BOLTS 427 1 ML TUBE	1
HOURGLASS 5/8	HOURGLASS 5/8 SHOCK BUSHING	2
P837	STAB TAPERED STUD/141264	1
140629	EB6 STUD BAG - P932/140629	1
7146-B	TJ TRACK BAR/STAB BRACKET	1
12STVCTN	1/2"STOVER COARSE, LOCK NUT	1

1. Park the vehicle on flat level ground & set the emergency brake.
2. Properly support the front of the vehicle & remove the OEM track bar & steering stabilizer.
3. Install the new Skyjacker front adjustable track bar by greasing & installing the two polyurethane bushings (Part # 2888) & sleeve (Part # 142121).
4. Insert the bushing end of the new Skyjacker front adjustable track bar into the OEM steering stabilizer location on the passenger side of the axle.  
**Note:** Not the OEM track bar location.



5. Install the new Skyjacker steering stabilizer mounting bracket. **Note:** The tab goes over the sway bar end link stud with the OEM nut. Use the supplied 1/2" x 2 1/2" flat socket head bolt & stover nut to bolt the new bracket to the track bar. (See Photo # 1)  
**Note:** In extreme situations depending on the pinion angle & caster settings, the drag link may contact this bracket when turning. This bracket can be slightly ground for additional clearance.



6. Install the frame end of the new Skyjacker track bar by following the hardware as shown. (See Photos # 2 & 3) **Note:** Be sure to keep the rod end square (parallel) with the frame mount & no more than 1/2" of threads are extended from the bar (including jam nut).

7. Hold the rod end in place with a crescent wrench & tighten using a wrench on the jam nut.
8. Install the frame end of the new Skyjacker track bar by following the hardware as shown. (See Photos # 14 & # 15) **Note:** Be sure to keep the rod end square (parallel) with the frame mount.

9. Check the vehicle to see if the body is centered over the tires & adjust the rod end as needed. Torque the bolt in the frame mount to 85-90 ft-lbs.

10. Install the new Skyjacker steering stabilizer mounting studs in the OEM hole the of drag link & new Skyjacker mounting bracket. Install the steering stabilizer on the new Skyjacker steering stabilizer studs. (See Photo # 4)

