



## #T5306 Installation Instructions 2007-2010 Toyota Tundra Front Differential Drop

### Read and understand all instructions and warnings prior to installation of product and operation of vehicle.

Zone Offroad Products recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known. Minimum tool requirements include the following: Assorted metric and standard wrenches, hammer, hydraulic floor jack and a set of jack stands. See the "Special Tools Required" section for additional tools needed to complete this installation properly and safely.

#### » PRODUCT SAFETY WARNING

Certain Zone Suspension Products are intended to improve off-road performance. Modifying your vehicle for off-road use may result in the vehicle handling differently than a factory equipped vehicle. Extreme care must be used to prevent loss of control or vehicle rollover. Failure to drive your modified vehicle safely may result in serious injury or death. Zone Offroad Products does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your modified vehicle under the influence of alcohol or drugs. Always drive your modified vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Always wear your seat belt.

#### » TECHNICAL SUPPORT

**Live Chat** provides instant communication with Zone tech support. Anyone can access live chat through a link on [www.zoneoffroad.com](http://www.zoneoffroad.com).

[www.zoneoffroad.com](http://www.zoneoffroad.com) may have additional information about this product including the latest instructions, videos, photos, etc.

Send an e-mail to [tech@zoneoffroad.com](mailto:tech@zoneoffroad.com) detailing your issue for a quick response.

**888.998.ZONE** Call to speak directly with Zone tech support.

#### Difficulty Level

easy ① 2 3 4 5 difficult

Estimated installation: .5 hours

#### Special Tools Required

Hydraulic Jack

#### Tire/Wheel Fitment

n/a

#### » PRE-INSTALLATION NOTES

1. Special literature required: OE Service Manual for model/year of vehicle. Refer to manual for proper disassembly/reassembly procedures of OE and related components.
2. Adhere to recommendations when replacement fasteners, retainers and keepers are called out in the OE manual.
3. Larger rim and tire combinations may increase leverage on suspension, steering, and related components. When selecting combinations larger than OE, consider the additional stress you could be inducing on the OE and related components.
4. Post suspension system vehicles may experience drive line vibrations. Angles may require tuning, slider on shaft may require replacement, shafts may need to be lengthened or trued, and U-joints may need to be replaced.
5. Secure and properly block vehicle prior to installation of Zone Offroad Products. Always wear safety glasses when using power tools.
6. If installation is to be performed without a hoist, Zone Offroad Products recommends rear alterations first.
7. Due to payload options and initial ride height variances, the amount of lift is a base figure. Final ride height dimensions may vary in accordance to original vehicle attitude. Always measure the attitude prior to beginning installation.

rev061313

## Kit Contents

| Qty | Part                          |
|-----|-------------------------------|
| 1   | Bolt pack - Differential drop |
| 3   | Skid Plate Spacers            |
| 2   | Diff drop spacers             |

### Important—measure before starting!

Measure from the center of the wheel up to the bottom edge of the wheel opening

LF \_\_\_\_\_ RF \_\_\_\_\_

LR \_\_\_\_\_ RR \_\_\_\_\_

## INSTALLATION INSTRUCTIONS

1. Park vehicle on clean flat and level surface. Block the rear wheels for safety.
2. Remove the front lower skid plate (if equipped).
3. Support the front differential with a hydraulic jack.
4. Remove the 2 front bolts from the vehicle with 19mm wrenches.
5. Lower the differential with the hydraulic jack.
6. Install the provided spacers in the gap. Install original cup washer on the new  $\frac{1}{2}$ " x 6" bolts. (Fig 1)
7. Install serrated edge flanged nut on top of the factory crossmember. Tighten to 65 ft-lbs.
8. Reinstall the factory skid plate (if equipped) with factory hardware to the crossmember under the radiator. Attach with (3) 8mm x 40mm bolts and 5/16" USS washers with (3) spacers to the differential mounting crossmember. Tighten to 25 ft-lbs.
9. Recheck hardware after 500 miles and at regularly scheduled maintenance intervals.



Fig. 1