

OPEN FIRST!!

Parts list for Master set # 3-18126

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Transmission mount Set: 3.1108

- 1 - 1036 mount
- 1 - 15.08.10.39 backing plate
- 2 - 15.03.48.39 (7/16" lockwasher)
- 4 - 15.03.42.39 (7/16" flat washer)
- 2 - 15.05.30.39 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions

Front end control arm bushing set: 3-3147

- 4 - 3092 upper control arm bushings
(Uppers must reuse factory hardware)
- 2 - 3134 lower control arm bushings (front pos.)
- 2 - 15.10.130.39 (.875"O.D. x .625" I.D. x 3.562" sleeve)
- 2 - 3135 lower control arm bushings (rear pos.)
- 2 - 15.10.34.39 (.875"O.D. x .625" I.D. x 3.000" sleeve)
- 2 - 9.11108 grease
- 1 - 17019 installation instructions

Front ball joint boot set: 9-13126

- 2 - 13014 upper ball joint boots.
- 2 - 13013 lower ball joint boots.

Tie rod boot set: 9.13101

- 2 - 13001 tie rod boots.

Front greaseable sway bar bushing and endlink set (32mm /1-1/4" bar): 3.5178

- 2 - 5354 bar bushings (1-1/4" bar diameter)
- 2 - 15.12.20.39 greaseable brackets.
- 8 - 4806 endlink grommets.
- 8 - 15.03.01.39 cupped washers.
- 2 - 15.10.21.39 (.562"O.D. x .375" I.D. x 2.6" sleeve)
- 2 - 15.05.04.39 (3/8"-16 x 7" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)
- 4 - 15.03.23.39 flat washer (.702"O.D. x .402" I.D.)
- 2 - 9.11108 grease tubes.
- 1 - 17145 installation instructions.

Rear leaf spring and shackle bushing set: 3.2128

- 8 - 2101 spring bushings
- 4 - 2102 bushings (shackle end)
- 6 - 15.10.08.39 (.750"O.D. x .563" I.D. x 3.000" sleeve)
- 2 - 9.11108 grease tubes.
- 1 - 17040 installation instructions



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Body mount set: 3.4148

Must reuse all factory hardware.

- 12 - 4076 bushings (top, all positions)
- 2 - 4078 bushings (bottom, position #1)
- 10 - 4079 bushings (bottom, positions #2-6)
- 1 - 17296 installation instructions.

Additional parts available for your vehicle:

Complete greaseable rear swaybar bushing set: # 3.5205 (22mm)

Shock boots fits most aftermarket shocks (Sold in pairs) set: # 9.8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.