

OPEN FIRST!!

Parts list for Master set # 8.18101 89-94 Toyota 4WD 1/2 Ton

Parts list:

Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front control arm bushing set: 8.3108

You must reuse all the factory metal parts.

- 2 - 3125 bushings, front upper position.
- 2 - 3126 bushings, rear upper position.
- 4 - 3129 bushings, front and rear lower position.
- 1 - 17019 installation instructions.

Rear leaf spring & shackle bushing set: 8.2108

- 8 - 2041 leaf spring bushing.
- 4 - 15.10.06.39 (.750"x .563"x 2.750" sleeve).
- 4 - 2092 rear frame shackle bushings.
- 1 - 17040 installation instructions.

Body mount set: 8.4103

You must reuse the lower factory washers.

- 4 - 4136 bushing (upper) position #2 & #3.
- 4 - 4137 bushing (lower) position #2 & #3.
- 4 - 15.10.273.39 (.750"x .500"x 1.900" sleeve).
- 2 - 4138 bushing (upper) position #1.
- 2 - 15.10.151.39(.625"x .437"x 1.640" sleeve).
- 2 - 4139 bushing (lower) position #1.
- 4 - 15.03.07.39 (2.500"x .437" I.D. washer).
- 2 - 15.03.59.39 (2.0" x .406" I.D. washer).
- 4 - 15.08.22.39 diamond shaped plate.
- 1 - 17170 installation instructions.

Tie-rod boot set: 2ea 9.13101

- 4 - 13001 tie-rod boots.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2008 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Complete front swaybar bushing & endlink set : 8.5106

(24mm diameter bar)

- 2 - 5115(24mm bushing reuse factory bracket).
- 8 - 4806 endlink grommet.
- 8 - 15.03.01.39 cupped washer.
- 2 - 15.05.04.39 (3/8-16 x 7" bolt).
- 2 - 15.07.01.40 (3/8-16 lock nut).
- 2 - 15.10.23.39 (.563"x .375"x 2.90" sleeve).
- 1 - 17039 installation instructions.

Additional parts available for your vehicle:

Shock boots

fits most aftermarket shocks (2 per set)
set # 9-8130

17194

13/JUL/09 BRH

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.