



2003 Ford Expedition - Rear Coil Spring Spacer Lift Kit

www.DaystarWeb.com
Tech Support Contact Info
Tech@DaystarWeb.com
Phone: 623.907.0081
Fax: 623.907.0088
841 South 71st Avenue
Phoenix, AZ 85043

Bill of Materials		
Part No.	Description	Qty
M03458	Coil Spring Spacer	2
M03457	Top Spacer	2
S10152	10mm-1.25 x 70mm Bolt	6
S10153	10mm Washer	6
S10539	10mm-1.25 Nut	6

Tools required	
Description:	Qty.
Wrench set & Socket set	1
Coil Spring Compressor	1
Floor Jack	1
Jack Stand	2+



Step(s)

DO NOT COMBINE WITH ANY OTHER SUSPENSION KIT


1. Layout all parts and check quantities against the Bill of Materials. Completely read instructions before beginning installation.
2. Jack the rear of the vehicle in accordance to manufacturer recommendation and support with jack stands, so that the rear two tires are off the ground
3. Remove the rear tires/wheels.
4. Separate the upper ball joint from the spindle. Use a ball joint separator or other suitable tool.
5. Remove upper strut nuts on the strut tower (3) on each side of vehicle that holds strut assembly to the strut tower (Fig. 2).

(Hint: Leave one nut on to prevent the strut from dropping out in the next step.)

6. Remove the lower strut bolt from the lower control arm and remove the strut assembly from the vehicle. (Note the direction of the bolt for reinstallation)

CAUTION: THE STRUT ASSEMBLY WILL DROP A LITTLE

7. Compress the coil spring on the strut assembly with a suitable coil spring compressor and remove the upper strut isolator mount nut.
8. Remove the compressed coil spring assembly from the strut.
9. Remove the coil spring isolator from the strut mounting plate.
10. Remove the 3 pressed in studs on the upper strut isolator mount and install the supplied 10mm bolts. Do not thread the nut on the backside.
11. Install the new Coil Spring Spacer to the upper strut mounting plate (Fig. 3).



(Continued on back)



Instruction Sheet P10598-00

© 2002 Daystar Products International Inc.



2003 Ford Expedition - Rear Coil Spring Spacer Lift Kit

12. Reinstall the compressed coil spring onto the strut assembly and re-attach the upper strut mounting plate.
13. Decompress the coil spring in the strut assembly. Make sure that the spring is seated correctly into the strut assembly alignment spiral.
14. Slide the Top Spacer onto the strut assembly over the new 10mm bolts (Fig. 4).
15. Install the strut assembly into the strut tower and start the upper three 10mm nuts with washer (Fig. 4). (Make sure that the bottom of the strut is aligned as well)
16. Install the lower strut bolt in the original position that it was removed. (Step 7)
17. Using the floor jack, raise the lower control arm and connect the upper ball joint on the upper control arm to the spindle.
18. Install the rear tires/wheels.
19. Lower the vehicle onto the ground and tighten the upper strut tower nuts. (3 on each side)
20. Torque all bolts to factory specifications. Re-torque all bolts after 500 miles.

www.DaystarWeb.com

Tech Support Contact Info


Tech@DaystarWeb.com

Phone: 623.907.0081

Fax: 623.907.0088

841 South 71st Avenue

Phoenix, AZ 85043



WARNING

This vehicle has been modified to enhance its performance. The steering, braking and handling of this vehicle will differ from standard passenger cars and trucks; this vehicle handles differently from an ordinary vehicle in driving conditions which may occur on streets, highways and off road.

Avoid unnecessary abrupt maneuvers, sudden stops, sharp turns and other driving conditions that could cause loss of control, possibly leading to a roll over or other accident that could result in serious injury or death to driver and passengers.

If larger tires are installed the speedometer will read lower than the vehicles actual speed.

**DRIVE WITH CARE, REDUCE SPEED
AND WEAR SEAT BELTS AT ALL TIMES.**

This kit should be installed by a professional mechanic.



Instruction Sheet P10598-00

© 2002 Daystar Products International Inc.